



E143i - SPARES - OVEN



ITEM No.	DESCRIPTION	SPARES CODE
1	BACK Baffle	733990030
2	OVEN ELEMENT 3.2KW	535420009
3	FAN MOTOR	732950001
4	OVEN FAN	535420010
5	OVEN LAMP C/W GLASS	732910390
6	OVEN CONTROL THERMOSTAT	535420006
7	AMBER INDICATOR	730962040
8	LIGHT SWITCH	535500037
9	OVEN CONTROL KNOB	733990031
10	OVEN DOOR SEAL	733990032
11	OVEN SAFETY THERMOSTAT	535420015




E143i - SPARES - CONTROLS




Part No.	DESCRIPTION	SPARES CODE
1	INDUCTION HEATER (16A)	733990005
2	8 POLE CABLE	733990009
3	CONTROL PANEL ASSEMBLY	733990025
4	INDUCTION CONTROL KNOB	733990003
5	MAINS PILOT LIGHT (RED)	730962010
6	HOB STAY ROD	733990012
7	5 POLE CABLE	733990010
8	CABLE GLAND	731350026
9	MAINS TERMINAL 7-WAY (PRE FEB 2025)	734000075
9a	MAINS TERMINAL 6-WAY (FEB 2025 ONWARDS)	731000006
10	SAFETY OR OPERATION RELAY	734243005
11	FUSE HOLDER	734310510
12	FUSE 2A	734243006
13	REAR COOLING FAN	735400360
14	HOB COOLING FAN THERMOSTAT	733990011
15	MAINS TERMINAL (3 WAY)	732910270
16	SPLITTER BOARD	733990008
17	CODING SWITCH	733990006
18	SWITCH SPACER	733990007



E143i - SPARES - FITMENTS



ITEM No.	DESCRIPTION	SPARES CODE
1	AIR FILTER	535200000
2	INDUCTION HOB ASSEMBLY	733990022
3	RH TOP DOOR HINGE	535200008
4	LH TOP DOOR HINGE	535200006
5	RH OUTER PANEL	535200001
6	WIRE SHELF HANGER	733990026
7	OVEN HANDLE	733990018
8	RH DOOR ASSEMBLY	733990027
9	LH DOOR ASSEMBLY	733990028
10	DOOR LATCH PIN PLATE	733990029
11	HOT CUPBOARD SHELF	730950010
12	RH BOTTOM DOOR HINGE	535200009
13	LH BOTTOM DOOR HINGE	535200007
14	ST/ST ADJUSTABLE LEG	535480067
15	CASTOR ASSEMBLY- SWIVEL	530964350
16	CASTOR ASSEMBLY - FIXED	535290031
17	LH OUTER PANEL	535200000
18	INDUCTION GENERATOR CRADLE	733990033
19	DOOR HINGE BUSH	537101290



DETAIL A