



ITEM	DESCRIPTION	FC2	FC3	FC4
1	HOB ASSEMBLY	730950000	730960000	730970000
2	DOOR ASSEMBLY RH	730950001	730960001	730970001
3	DOOR ASSEMBLY LH	730950002	730960002	730970002
4	CONTROL PANEL	730950003	730960003	730970003
5	GLASS SCREEN	730950004	730960004	730970004
6	LOWER FACIA	730950005	730960005	730970005
7	OUTER BACK PANEL - T	730950006	730960006	730970006
8	OUTER BACK PANEL	730950007	730960007	730970007
9	HALF GLASS SCREEN (NOT SHOWN)	730950008	730960008	730970008
10	OUTER SIDE PANEL	730950009	730950009	730950009
11	HOT CUPBOARD SHELVES	730950010	730950010	730950010
12	SIDE SCREEN	730950011	730950011	730950011
13	GLASS FIXING SCREW KIT	730950012	730950012	730950012
14	GLASS HOLDER	730950013	730950013	730950013